

CORNISHWARE®

Cornish Blue™



852720CB
Breakfast Plate
9" / 22.8cm



850504CB
Serve Bowl 31cm




852645CB
Covered Sugar Bowl



82124CB
Egg Cup Footed



850481CB
Cereal Bowl 6.5"



852744CB
Plate (side) 7"



82575CB
Dreadnought Jug
10oz/28cl



849201CB
Espresso Cup &
Saucer



852737CB
Dinner Plate 10"



855653CB
Beaker 27cl



82582CB
Dreadnought Jug
20oz/56cl



850573CB
Garlic Keeper



852728CB
Dinner Plate Large
12" / 28cm



82308CB
Butter Dish



82599CB
Dreadnought Jug
30oz/84cl



82605CB
Graduated Jug
20oz/56cl



850498CB
Pasta Bowl
9.5" / 24cm



849188CB
Cappuccino Cup &
Saucer



82186CB
Egg Cup (straight
sided)



82148CB
Honey/Marmalade
Jar

CORNISHWARE®

Cornish Blue™



856612CB
Hot Chocolate
Mug 15oz



81998CB
Mug 15oz



857831CB
Storage Jar "Biscuit"
168cl



83107CB
Storage Jar Plain
168cl



855646CB
Juice Jug 110cl



855640CB
Oil & Vinegar
Drizzler Set



82933CB
Storage Jar Plain
84cl



852621CB
Tea Cup & Saucer



83411CB
Mortar Pestle
80x150mm



82704CB
Pudding Basin 112cl



82957CB
Storage Jar "Coffee"
84cl



82506CB
Teapot 30oz



82001CB
Mug 10oz



82780CB
Pudding Basin Lipped
112cl



82971CB
Storage Jar "Sugar"
84cl



83206CB
Utensil Jar



853192CB
Mug 12oz



82340CB
Salt & Pepper Shaker



82984CB
Storage Jar "Tea" 84cl



83251CB
Bread Crock